




















BS104

STRENGTH






Assembly Instructions





Parts List

bracket set			Inclined bracket set			Seat part			Seat back part		
											
1		1 pc	2		1 pc	3		1 pc	4		1 pc
Seat back pad			Seat pad			short foam			axis		
											
5		1 pc	6		1 pc	7		2 pc	8		1 pc
thick spacer			spacer			end cap			foam spacer		
											
9		2 pc	10		4 pc	11		2 pc	12		2 pc
Foam inner cover			Foam inner cover			M12*35 Hexagon Screw			M8*16 Countersunk head hexagon socket screw		
											
13		2 pc	14		2 pc	15		2 pc	16		2 pc

Parts List

M8*25 Half round head hexagon socket head screw			M8*70 Half round head hexagon socket head screw			Φ8 Flat pad			Φ12 Flat pad		
											
17		4 pc	18		3 pc	19		2 pc	20		2 pc
Φ12 spring washer											
											
21		2 pc									

Step (1)



Step (2)

